



How to install the latest FTDI USB DLL driver

Instructions for Windows 7 through Windows 11



Download the files listed below.

- https://daytona-twintec.com/content/DTT/Software/CDM212364_Driver_Setup.exe
- https://daytona-twintec.com/content/DTT/Software/CDM_Driver_UninstallerGUI_v1.5.exe

- 1 Unplug all USB devices.
- 2 Reboot your PC.
- 3 Remove Existing Driver --> Run --> CDM_Driver_UninstallerGUI_v1.5.exe; then perform the following:
 - Run the program from the installer: **CDMUninstaller.exe** as Administrator.
 - Clear the **Product ID**.
 - Click **Add**.
 - Click **Remove Devices**.
 - Close the program.
- 4 Reboot the PC — verify that no USB devices are connected.
- 5 Run --> **CDM212364_Driver_Setup.exe** as Administrator with **NO** USB devices connected.
- 6 Connect your Daytona Twin Tec USB device to the PC.
- 7 Use Device Manager to identify which COM port is assigned to your device.
- 8 Start your software and set it to use the correct COM port.

Tip: In Device Manager → Ports (COM & LPT) → [Your FTDI Port] → Advanced..., set **Latency Timer** to **2 ms** for faster transfers.